



## FITTING 12 OR 36 TOOTH TRIGGER DISC

- 1) Ensure removal of original timing disc fitted to Harmonic Damper.
- 2) Align Top Dead Center (TDC), indicated by the "0" mark, to the correct location.
- 3) Use new bolts provided to fit trigger, tension bolts:

M6 countersunk	11Nm
M6 low head cap bolt	13Nm

We recommend thread locking compound on all bolts fitted.

**#GoHarder with #RossPerformanceParts**

